Aspire 5735/5735Z/5335 Series

Quick Guide

Copyright © 2008. Acer Incorporated. All Rights Reserved. Aspire 5735/5735Z/5335 Series Quick Guide Original Issue: 08/2008 Changes may be made periodically to the information in this publication without obligation to notify any person of such revisions or changes. Such changes will be incorporated in new editions of this manual or supplementary documents and publications. This company makes no representations or warranties, either expressed or implied, with respect to the contents hereof and specifically disclaims the implied warranties of merchantability or fitness for a particular purpose. Record the model number, serial number, purchase date and place of purchase information in the space provided below. The serial number and model number are recorded on the label affixed to your computer. All correspondence concerning your unit should include the serial number, model number and purchase information. No part of this publication may be reproduced, stored in a retrieval system, or transmitted, in any form or by any means, electronically, mechanically, by photocopy, recording or otherwise, without the prior written permission of Acer Incorporated. Aspire 5735/5735Z/5335 Series Notebook PC

Model number: ______

Serial number: ______

Date of purchase: ______

Acer and the Acer logo are registered trademarks of Acer Incorporated. Other companies' product names or trademarks are used herein for identification purposes only and belong to their respective companies.

First things first

We would like to thank you for making an Acer notebook your choice for meeting your mobile computing needs.

Your guides

To help you use your Acer notebook, we have designed a set of guides:

First off, the Just for Starters... poster helps you get started with setting up your computer.

The Aspire Series Generic User Guide contains useful information applying to all models in the Aspire product series. It covers basic topics such as Acer's Empowering Technology, using the keyboard, audio, etc. Please understand that due to its nature, the **Generic User Guide** as well as the **AcerSystem User Guide** mentioned below will occasionally refer to functions or features which are only contained in certain models of the series, but not necessarily in the model you purchased. Such instances are marked in the text with language such as "only for certain models".

The **Quick Guide** introduces you to the basic features and functions of your new computer. For more on how your computer can help you to be more productive, please refer to the AcerSystem User Guide. This guide contains detailed information on such subjects as system utilities, data recovery, expansion options and troubleshooting. In addition it contains warranty information and the general regulations and safety notices for your notebook. It is available in Portable Document Format (PDF) and comes preloaded on your notebook. Follow these steps to access it:

1 Click on Start, All Programs, AcerSystem.

2 Click on AcerSystem User Guide.



Note: Viewing the file requires Adobe Reader. If Adobe Reader is not installed on your computer, clicking on AcerSystem User Guide will run the Adobe Reader setup program first. Follow the instructions on the screen to complete the installation. For instructions on how to use Adobe Reader, access the Help and Support menu.

Your Acer notebook tour

After setting up your computer as illustrated in the **Just for Starters...** poster, let us show you around your new Acer notebook.

Top view



#	Icon	Item	Description
1		Acer Crystal Eye webcam	Web camera for video communication (only for certain models).

#	Icon	Item	Description
2		Display screen	Also called Liquid-Crystal Display (LCD), displays computer output.
3	Ф	Power button	Turns the computer on and off.
4	e	Empowering key	Launch Acer Empowering Technology.
5		Keyboard	For entering data into your computer.
6		Touchpad	Touch-sensitive pointing device which functions like a computer mouse.
7/14		Status indicators	Light-Emitting Diodes (LEDs) that light up to show the status of the computer's functions and components. Please refer to the Generic User Guide for more details.
8		Click buttons (left and right)	The left and right buttons function like the left and right mouse buttons.
9		Palmrest	Comfortable support area for your hands when you use the computer.
10		Speakers	Left and right speakers deliver stereo audio output.
11	100	Microphone	Internal microphone for sound recording.
12		Easy-launch buttons	Buttons for launching frequently used programs. Please refer to the Generic User Guide for more details.
13	VOL+/ VOL-	Volume up/ Volume down	Increases the sound volume/Decreases the sound volume.

Closed front view




#	Item	Description
1	Latch	Locks and releases the lid.

Rear view



#	Item	Description
1	Ventilation slots	Enable the computer to stay cool, even after prolonged use.

Left view




#	lcon	Item	Description
1		External display (VGA) port	Connects to a display device (e.g., external monitor, LCD projector).
2	용	Ethernet (RJ-45) port	Connects to an Ethernet 10/100/1000-based network.
3	● ✓•+	USB 2.0 port	Connects to USB 2.0 devices (e.g., USB mouse, USB camera).
4	∠ en	Microphone jack	Accepts inputs from external microphones.
5	ဂ	Headphones/ speaker/line-out jack	Connects to audio line-out devices (e.g., speakers, headphones).
6	S PRO	5-in-1 card reader	Accepts Secure Digital (SD), MultiMediaCard (MMC), Memory Stick (MS), Memory Stick Pro (MS PRO), and xD-Picture Card.
	MULTIMEDIACARD		Note: Push to remove/install the card. Only one card can operate at any given time.
7	ExpressCard / 54	ExpressCard/54 slot	Accepts one ExpressCard/54 module. Note: Push to remove/install the card.

Right view



#	lcon	Item	Description
1		Optical drive	Internal optical drive; accepts CDs or DVDs.
2		Optical disk access indicator	Lights up when the optical drive is active.
3		Optical drive eject button	Ejects the optical disk from the drive.
4		Emergency eject hole	Ejects the optical drive tray when the computer is turned off. Note: Insert a paper clip to the emergency eject hole to eject the optical drive tray when the computer is off.
5		Modem (RJ-11) port	Connects to a phone line.
6	==	DC-in jack	Connects to an AC adapter.
7	ĸ	Kensington lock slot	Connects to a Kensington-compatible computer security lock.

Base view



#	lcon	Item	Description
1	∄	Battery bay	Houses the computer's battery pack.
2		Battery release latch	Releases the battery for removal.
3		Battery lock	Locks the battery in position.
4		Memory compartment	Houses the computer's main memory.
5		Hard disk bay	Houses the computer's hard disk (secured with screws).
6		Ventilation slots and cooling fan	Enable the computer to stay cool, even after prolonged use. Note : Do not cover or obstruct the opening of the fan.

Specifications

Operating system	Genuine Windows Vista®
Platform	 Intel[®] Core[™]2 Duo processor*
	Intel [®] Pentium [®] dual-core processor*
	Intel [®] Celeron [®] processor*
	Mobile Intel [®] GL40/GM45 Express Chipset*
	Intel [®] Wireless WiFi Link 5100/5300*
	Acer InviLink [™] Nplify [™] 802.11b/g/Draft-N*
	• Acer InviLink [™] 802.11b/g*
System memory	Dual-channel support
,	 Up to 2 GB of DDR2 667 MHz memory, upgradeable to 4 GB using two soDIMM modules
Display	• 15.6" HD 1366 x 768
Graphics	Mobile Intel® GL40/GM45 Express Chipset*
Storage	2.5" hard disk drive
subsystem	Optical drive option:
	DVD-Super Multi double-layer drive
	• 5-in-1 card reader
Audio	Two built-in stereo speakers
	High-definition audio support
	MS-Sound compatible Duilt in microphone
Communication	Built-in microphone
Communication	 Integrated Acer Crystal Eye webcam* WLAN:
	Intel® Wireless WiFi Link 5100/5300*
	Acer InviLink [™] Nplify [™] 802.11b/g/Draft-N*
	Acer InviLink [™] 802.11b/g*
	WPAN: Bluetooth® 2.0+Enhanced Data Rate (EDR)*
	LAN: Gigabit Ethernet; Wake-on-LAN ready
D' '	Modem: 56K ITU V.92; Wake-on-Ring ready
Dimensions	• 383 (W) x 250 (D) x 15/37 (H) mm 15.08 (W) x 9.84 (D) x 0.59/1.46 (H) inch
Privacy control	BIOS user, supervisor, HDD passwords
-	Kensington lock slot
Power	• ACPI 3.0
subsystem	 48.8 W 4400 mAh
	• 3-pin 65 W AC adapter
	ENERGY STAR® 4.0*

Special keys	 105-/106-key keyboard
and controls	 Touchpad pointing device
I/O interface	• ExpressCard [™] /54 slot
	• 5-in-1 card reader (SD/MMC/MS/MS PRO/xD)
	• USB 2.0 port
	 External display (VGA) port
	 Headphones/speaker/line-out jack
	Microphone-in jack
	• Ethernet (RJ-45) port
	 Modem (RJ-11) port
	DC-in jack for AC adapter
Environment	Temperature:
	 Operating: 5 °C to 35 °C Non-operating: -20 °C to 65 °C
	Humidity (non-condensing):
	Operating: 20% to 80%Non-operating: 20% to 80%
Note	* Only for certain models.

Note: The specifications listed above are for reference only. The exact configuration of your PC depends on the model purchased.